Direct connection for Windows

dhcp_server_for_windows

Re-burning SD Card

Only for sMS-200, to initialize whole system.

burn_sdcard_image

File Tag Encoding and Display Issues

https://kb.roonlabs.com/FAQ:Some_characters_are_not_displaying_properly

IckStream in LMS

how_to_install_ickstream_app_in_lms



LMS should be restart when you reboot Eunhasu because IckStream plugin could not get login information just after reboot.

From:
https://www.docs.sotm-audio.com/ - **SOtM docs**

Permanent link:
https://www.docs.sotm-audio.com/doku.php?id=en:eunhasu:advanced&rev=1488956758

Last update: **2017/03/08 02:05**