

1. Open Eunhasu Web GUI
2. Run Squeezelite mode and
 1. A. Start Squeezelite mode and open LMS.
3. Click Settings button
 1. A. If the ickStream app was installed, you can see the app in Home → My Apps.
 2. B. Click Settings button at the right bottom side.
4. Install ickStream App
 1. A. Go to Plugins tabs, and scroll down to the bottom page.
 2. B. Enter the url below in the blank box at the bottom side of the page and click Apply button. SMS-200: <http://repository.ickstream.com/squeezebox/repository-linuxarmhf.xml> and SMS-1000: <http://repository.ickstream.com/squeezebox/repository-linux.xml>
 3. C. Once the new windows appear, click OK to install ickStream App.
 4. D. Enable 'ickStream' at Updated plugins available section, and click Apply button.
 5. E. Click 'Reboot Now' and open LMS again.
5. Check ickStream app.
 1. A. You can see ickStream app in My Apps.
 2. B Check Settings → Advanced tab , the ickStearm setting menu will be appeared as the image below.

From:

<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:

https://www.docs.sotm-audio.com/doku.php?id=en:how_to_install_ickstream_app_in_lms&rev=1479354267

Last update: **2016/11/16 22:44**

