
2025/10/06 18:56 1/4 MinimServer


MinimServer

MinimServer is one of the best UPnP Audio Server. MinimServer collects user's music and operated by a DLNA control point such as Bubble UPNP app. You can search and playback your music file in more convenient ways.


MinimServer should be installed by an user. Installation is available in MinimServer config page.



MinimServer can be controlled in MinimServer config page, start, open, stop or restart after done the installation.



Content directory of MinimServer setting has to be set in MinimServer config page which could be open after starting MinimServer.




First, you have to accept MinimServer license terms to use.

2025/10/06 18:56 3/4 MinimServer

MinimServer License MinimServer 0.8.4, Copyright (c) 2012-2016 Simon Nash. All rights reserved. By downloading, installing or using this software, you accept the following license conditions: You may use this software free of charge for personal and domestic purposes. Subject to condition 2, you may use this software free of charge for business purposes. If you would like to make a voluntary donation to support MinimServer development, please visit the Donate page. 2. You may not redistribute this software (with or without modification), and you may not sell or distribute any product containing this software (with or without modification). 3. You may not decompile, disassemble or reverse engineer this software. 4. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS Please confirm your acceptance of these terms by selecting the "I accept" option below and clicking Confirm. I accept the MinimServer license terms Confirm OI do not accept the MinimServer license terms

Set Content directory and press 'Update' button and press 'Rescan' button.



- Content directory shoule be /mw/data/music to collect music in Eunhasu system.
- If /mw/data/music space are 100% full, the main system would be in abnormal status and not be operating normally.

Last Updated: 2021/06/01 15:02

From:

https://www.docs.sotm-audio.com/ - SOtM docs

Permanent link:

×

https://www.docs.sotm-audio.com/doku.php?id=en:minimserver&rev=1622574121

Last update: 2021/06/01 15:02