



How to update the sMB-Q370 Bios version

If there is .exe Bios file


1. Boot up with WindowsOS. Download D8260T36.zip file and unzip properly.



2. Run D8260T36.exe as administrator.




3. Wait till the update would be completed, then the windows will be closed.






If there is .rom Bios file


1. Download D8260T36.zip and extract(unzip). 2. Copy D8260T36.rom file to an USB drive. 3. Connect the USB drive to any SMB-Q370 USB port and then turn on. 4. Press DEL Key to enter BIOS menu.




5. Go to Security→Secure Flash Update→Path for ROM Image→Select a File system→Select File, and select D8260T36.rom > OK to reboot System.









6. Recovery is generating in BIOS .




7. Select Recovery→Proceed with flash update and wait till finished the update.



8. Once finished the update, press any key to reboot System.



9. Check the BIOS version is now D8260T36.



BIOS download file

- [D8260T36.zip](#)

From:

<https://docs.sotm-audio.com/> - **SOTM docs**

Permanent link:

https://docs.sotm-audio.com/doku.php?id=en:smb_q370_bios_update

Last update: **2024/01/03 20:29**

