

- sDP-1000EX Main Audio USB
- 2가

가

sDP-1000EX

Main

- sDP-1000EX Main

[sDP-1000Ex_V2.1_20190705.zip](#)

- Flip

[Flip 3.4.7 software](#)

sDP-1000EX

sDP-1000EX PC USB
DFU

sDP-1000EX Audio USB

- OLED
- OLED




Flip

Flip , Flip




, AT90USB1286




USB Port Connection 'Open'



'Load Hex File



'Run'



가 , sDP-1000EX Audio USB

- Audio , OLED가
- , OLED ,



Audio USB

- Audio USB

[app_usb_aud_l1_2xoxs_v6.c2.bin](#)


- SotM 가

[SotM USB Audio 2.0 Driver v2.23.0](#)


SotM USB Audio Firmware Upgrade

1. sDP-1000EX PC USB
2. Windows OS

sDP-1000EX
SotM USB Audio Firmware Upgrade




'Browse



'Start'



가 , SOTM USB Audio Control Panel sDP-1000EX



sDP-1000EX FW

- [sDP-1000Ex_V2.1_20190705.zip](#)
- [app_usb_aud_l1_2xoxs_v6.c2.bin](#)

Utilities

- [Flip 3.4.7 software](#)
- [SOTM USB Audio 2.0 Driver v2.23.0](#)

From:
<https://www.docs.sotm-audio.com/> - **SotM docs**

Permanent link:
https://www.docs.sotm-audio.com/doku.php?id=ko:how_to_upgrade_sdp-1000ex_fw

Last update: **2022/03/16 01:16**

