

- SMS-200 V0.3.0 SMS-1000SQ Eunhasu V0.3.0
- Wifi dongle
 - RTL8812AU

Simple Instruction


USB

Wifi USB




System config

'Wifi'





'Wifi Router'





'Connect'





IP



'Remove Wifi Information'

AP 가

The screenshot shows the 'System config' interface with the 'Wifi' tab selected. It includes a 'Names' tab, a 'Background' tab, and a 'Wifi' tab. Below the tabs, there is a message: 'Set wifi configurations. If you could not see any 'Wifi Router', please reload page.' The configuration area contains an 'On' toggle switch, a 'Wifi Router' dropdown menu, an 'SSID' input field, a 'Password' input field, and a 'Connect' button. Below these are two status bars: 'Connected' with the value 'A3004-5G_SOTM' and 'Wireless IP' with the value '192.168.0.44'. A 'Remove Wifi information' button is highlighted with a yellow circle and a mouse cursor. A 'Cancel' button is located below the status bars. At the bottom, there is a 'System information' section with details like 'Eunhasu Web interface version: V0.3.0', 'IP address: 11.11.0.6', 'MAC address: 00:e0:91:20:96:3b', and 'Tag ID: 923727c'. Below that is an 'Eunhasu information' section with links for 'About' and 'Change Log'.

A yellow warning banner with a black exclamation mark icon on the left. To the right of the icon are three bullet points. The text in Korean reads: '• Eunhasu V0.3.0', '• 가', and '• 가'.

From:
<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:
https://www.docs.sotm-audio.com/doku.php?id=ko:how_to_use_wifi_in_eunhasu&rev=1484880969

Last update: **2017/01/19 21:56**