

- SMS-200 V0.3.0      SMS-1000SQ Eunhasu V0.3.0
- Wifi dongle
  - RTL8812AU

## Simple Instruction


USB

Wifi USB




System config

'Wifi'





### 'Wifi Router'






'Connect'







IP



'Remove Wifi Information'

AP 가





- Eunhasu V0.3.0
- 가
- 가

From:  
<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:  
[https://www.docs.sotm-audio.com/doku.php?id=ko:how\\_to\\_use\\_wifi\\_in\\_eunhasu&rev=1484880999](https://www.docs.sotm-audio.com/doku.php?id=ko:how_to_use_wifi_in_eunhasu&rev=1484880999)

Last update: **2017/01/19 21:56**

