

- sMS-200 V0.3.0      sMS-1000SQ Eunhasu V0.3.0
- Wifi dongle
  - RTL8812AU


# Simple Instruction

USB

Wifi USB


. Wifi

LAN





System config

'Wifi'




### 'Wifi Router'







가

'Connect'







IP



'Remove Wifi Information'

AP 가





- Eunhasu V0.3.0
- 
- 

가

가

Last Updated: 2017/01/24 21:18

From:  
<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:  
[https://www.docs.sotm-audio.com/doku.php?id=ko:how\\_to\\_use\\_wifi\\_in\\_eunhasu&rev=1485310708](https://www.docs.sotm-audio.com/doku.php?id=ko:how_to_use_wifi_in_eunhasu&rev=1485310708)

Last update: **2017/01/24 21:18**

