

1. SMS-200 을 고정 IP 로 설정합니다. 아래 예시:

- IP - 10.0.0.2
- subnet - 255.255.255.0
- gateway - 10.0.0.1

2. PC를 고정 IP 로 설정합니다. 아래 예시:

- IP - 10.0.0.1
- subnet - 255.255.255.0
- gateway - 비움

참고: <https://www.online-tech-tips.com/computer-tips/windows-mac-assign-static-ip-address/>

From:

<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:

https://www.docs.sotm-audio.com/doku.php?id=ko:kb:direct_connection

Last update: **2018/10/07 21:10**

