

# Roon

Roon

가

. Control, Output, Core

Roon

## Roon Ready


Roon Ready Roon Server, Roon Remote

. Roon Ready

RoonBridge

. hqplayer\_naa

## Roon Ready config






- **Audio device config:** USB DAC
- **Volume mode:** Fixed, Software, Device Controls
- **DSD mode:** DSD NONE, NATIVE, DOP, DCS, NATIVE/DOP, NATIVE/DCS
- **DSD rate:** DSD x64, x128, x256
- **Buffer duration:** 0.01 ~ 0.1

- Resync delay: 0.1 ~ 0.5 가 0.01


## Roon Ready


Remote Roon Server Roon Ready 'Active' Roon  
Settings > Audio Roon Ready SMS-200





sMS-200 Audio zone






# Roon Server

Roon Server    Roon Core    Roon Output    Roon Remote    [Roonlabs](#)


Roon core 1.3    'sample rate conversion'    SMS-1000SQ  
 DSD    . Max PCM rate    384 khz

# Roon Server


[Eunhasu](#)    Roon Server    'Active'




[Roon Server](#) 가 'Active'    Roon remote    Roon Core    SMS-1000SQ





Core





Audio Zone



 Roon Server 가

: 2017/05/25 22:32

From: <https://docs.sotm-audio.com/> - **SOTM docs**

Permanent link: <https://docs.sotm-audio.com/doku.php?id=ko:roon>

Last update: **2017/05/25 22:32**

