

Roon

Roon , Control, Output, Core
Roon

Roon Ready

Roon Ready Roon Server, Roon Remote

RoonBridge , hqplayer_naa

. Roon Ready



Roon Ready
'Active'



. Roon Ready가





- **Audio device config:** USB DAC
- **Volume mode:** Fixed, Software, Device Controls
- **DSD mode:** DSD NONE, NATIVE, DOP, DCS, NATIVE/DOP, NATIVE/DCS
- **DSD rate:** DSD x64, x128, x256
- **Buffer duration:** 가
- **Resync delay:** 0.1 ~ 0.5 0.01

Roon Ready

Roon Ready 'Active' Roon Desktop Setting > Audio Roon
Ready SMS-200



Audio Zone



Roon Server


Roon Server Roon Core Roon Output

Roon Remote


. [Roonlabs](https://www.roonlabs.com)

Roon



Roon Server



Roon Server 가 (Active) Roon Desktop Core SMS-1000SQ Core



Core



Audio Zone



: 2017/01/22 22:48

From:
<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:
<https://www.docs.sotm-audio.com/doku.php?id=ko:roon&rev=1485143287>

Last update: **2017/01/22 22:48**

