

# Roon

Roon

가

. Control, Output, Core

Roon

## Roon Ready


Roon Ready Roon Server, Roon Remote

. Roon Ready

RoonBridge

. hqplayer\_naa

## Roon Ready config



- **Audio device config:** USB DAC
- **Volume mode:** Fixed, Software, Device Controls
- **DSD mode:** DSD NONE, NATIVE, DOP, DCS, NATIVE/DOP, NATIVE/DCS
- **DSD rate:** DSD x64, x128, x256
- **Buffer duration:** 가

- Resync delay: 0.1 ~ 0.5 0.01

# Roon Ready


Roon Ready

'Active'  
SMS-200

Roon Desktop


Setting > Audio

Roon





Audio Zone






# Roon Server

Roon Server   Roon Core   Roon Output   Roon Remote   [Roonlabs](#)

# Roon Server

[Roon Server](#)




[Roon Server](#) 가 (Active)   Roon Desktop   Core   SMS-1000SQ   Core




Core





Audio Zone



: 2017/01/25 00:23

From:  
<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:  
<https://www.docs.sotm-audio.com/doku.php?id=ko:roon&rev=1485321800>

Last update: **2017/01/25 00:23**

