


# Roon

Roon 가 Roon . Control, Output, Core . Roon .

## Roon Ready

Roon Ready Roon Server, Roon Remote . Roon Ready .  
RoonBridge , . hqplayer\_naa .

### Roon Ready config




- **Audio device config:** USB DAC
- **Volume mode:** Fixed, Software, Device Controls
- **DSD mode:** DSD NONE, NATIVE, DOP, DCS, NATIVE/DOP, NATIVE/DCS
- **DSD rate:** DSD x64, x128, x256
- **Buffer duration:** 가

- Resync delay: 0.1 ~ 0.5 0.01

# Roon Ready

Remote Roon Server . Roon Ready 'Active' . Roon  
Setting > Audio Roon Ready SMS-200





sMS-200 Audio zone



# Roon Server

Roon Server   Roon Core   Roon Output

Roon Remote


[Roonlabs](#)

# Roon Server

Eunhasu

Roon Server

'Active'




Roon Server 가 'Active'

Roon Desktop



Core

sMS-1000SQ

Core



Core



### Audio Zone



: 2017/01/25 19:12

From:  
<https://www.docs.sotm-audio.com/> - **SotM docs**

Permanent link:  
<https://www.docs.sotm-audio.com/doku.php?id=ko:roon&rev=1485389575>

Last update: **2017/01/25 19:12**

