


How to update the sMB-Q370 Bios version

- Bios.exe


1. Windows

D8260T36.zip




2. WINDOWS

D8260T36.exe



3. 가

가




- Bios.rom

1. D8260T36.zip
SMB-Q370

2. D8260T36.rom
4. DEL Key


USB
BIOS



3. USB
가 .




5. Security→Secure Flash Update→Path for ROM Image→Select a File system→Select File


D8260T36.rom OK System reboot









6. BIOS Recovery가 .




7. Recovery→Proceed with flash update



8. System reboot



9. BIOS version D8260T36



BIOS

- [D8260T36.zip](#)

From:

<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:

https://www.docs.sotm-audio.com/doku.php?id=ko:smb_q370_bios_update

Last update: **2024/01/03 20:31**

