

sMS-200



User Guide

sMS-200

sMS-200
sMS-200


- Roon Ready : Roon Server, Tidal, Roon Server, 가
- Squeezelite : LMS(Logitech Media Server), USB, Tidal, Qobuz, Internet Radio
- MPD, USB : .DLNA audio renderer, MPD, DLNA server, DLNA control point, DLNA server, PC, NAS, DLNA
- HQPlayer : [HQPlayer Desktop](#)

How to use


1. sMS-200 : USB, USB, USB
2. sMS-200 : Ethernet, LAN
3.
 - Roon Ready : Roon Server가 가
 - SqueezeLite : MPD: USB, sMS-200, USB 2.0, Network music folder, Eunhasu, Library config
 - DLNA : DLNA control point, sMS-200, DLNA server
4. (9V/2A) (mBPS-d2s)

- POWER IN
5. 30 SMS-200 sMS-200 <http://eunhasu/>
SMS-200 IP SMS-200 Web GUI Eunhasu
iOS <http://eunhasu.local/> Eunhasu
 6. Eunhasu
 - 7.
 8. 'Start' 가 10 'ACTIVE'가
 9. config USB
 10. controller Start 'Stop'
 11. SMS-200 , System setup System power off


Roon ready



Squeezelite



HQplayer



From:

<https://www.docs.sotm-audio.com/> - **SotM docs**

Permanent link:

https://www.docs.sotm-audio.com/doku.php?id=ko:sms-200_user_guide&rev=1474430478

Last update: **2016/09/21 00:01**

