

MPD / DLNA renderer

MPD is a high performance music playback service that can play music files on a USB storage device or network share folder. Eunhasu has only DLNA audio renderer not include other DLNA stack. You can use Eunhasu with a DLNA server. However, [sMS-1000SQ Eunhasu](#) product has a DLNA server feature which is [MinimServer](#). You could use 'MPD / DLNA renderer' with [MinimServer](#) if you have [sMS-1000SQ Eunhasu](#).

MPD config

Output name config

Enter MPD output name

Audio device config

Select Audio device and option. When you select Native DSD type 2, your DAC supports 32-bit DSD_U32_BE sample formats (e.g. XMOS based USB DACs and Marantz/Kenwood DACs). Type 0 is for using 8-bit DSD_U8 format like the Botic driver for the BeagleBone Black.

MPD buffer config

Enter MPD buffer values

MPD & DLNA feature config

Tidal streaming config

Enter your Tidal ID&Password. And select Tidal streaming quality according to your account type, 'low' and 'high' are for Premium account and 'lossless' is for 'HIFI' account.

Qobuz streaming config

Enter your Qobuz ID&Password. And select Qobuz streaming format, 'normal' is for mp3/210 and 'lossless' is for FLAC.

Save changes

Cancel

Uninstall

- **Name:** A name of Eunhasu's MPD & DLNA appearing on MPD controlling App and DLNA controlling App. This can be changed if you need.
- **Audio device config:** Select a radio button of USB DAC which is going to use and click 'Save changes' to use the USB DAC.
- **DOP enable:** Check for using DOP function while playing DSD music file.
- **Native DSD type 0:** To use 8-bit DSD_U8 format DAC. (e.g. BeagleBone Black using Botic driver)
- **Native DSD type 2:** To use 32-bit DSD_U32_BE format DAC. (e.g. XMOS-based USB DACs or Marantz/Kenwood DAC)
- **Replay gain:** Choose Replay gain among None, Album or Track.
- **OpenHome DLNA Renderer:** Check for using OpenHome DLNA Renderer feature.
- **Library auto update:** Check for auto-scanning and updating the library.
- **MPD Buffer config:** Adjust the buffer value according to your environment.
 - **Audio buffer size:** Specify the size of the audio buffer in Kbytes.
 - **Buffer before play:** Specify the amount of audio buffer that must be filled before playing music file. Increase the value if the song is cut when moving to the next music file. Only numbers between 0 and 100 can be entered.
 - **Buffer time:** Set the buffer length of the music file data to be sent to the audio device in microseconds.
 - **Period time:** : Set the transmission interval of music file data to be transmitted to the

audio device in microseconds.

Detailed information about each item of Buffer config is available at the following URL.

<https://linux.die.net/man/5/mpd.conf>

- **Tidal streaming config:** This is for users who use Tidal streaming with mpd / dlina feature. Enter your Tidal account information to the ID and Password fields. In Quality field, set the proper value according to your Tidal account. Select low / high quality for Tidal premium account, or Lossless for HIFI account.
- **Quboz streaming config:** This is for users who use Qobuz streaming with mpd / dlina feature. Enter your Qobuz account information to the ID and Password fields. In Format field, set the proper value according to your Quboz account. Select normal for playing mp3 music source, and lossless for playing FLAC music source.




Native DSD feature is available from Eunhasu V0.3.2.

MPD clients

- MPDroid: <https://play.google.com/store/apps/details?id=com.namelessdev.mpdroid>
- M.A.L.P. - MPD Client: <https://play.google.com/store/apps/details?id=org.gateshipone.malp>
- MPod: <https://itunes.apple.com/kr/app/mpod/id285063020?mt=8> *out of dated*
- MPDlux: <https://itunes.apple.com/us/app/mpdluxe/id991758069?mt=8>
- Gnome Music Player Client: <https://gmpclient.org/installation>
- Chimney: <https://www.microsoft.com/en-us/store/p/chimney/9wzdncrfj6jx>

Reference: <http://mpd.wikia.com/wiki/Clients>



how to connect and access NAS in SMS-200



How to connect NAS to SqueezeLite or MPD/DLNA on SMS-200

Last Updated: 2018/05/01 02:55

From:
<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:
<https://www.docs.sotm-audio.com/doku.php?id=en:mpd&rev=1525157717>

Last update: **2018/05/01 02:55**

