

Make the USB installation disk

Download the Eunhasu ISO image file

- [Eunhasu X86 V0.5.7](#)
- [Eunhasu X86 V0.5.8](#)
- [Eunhasu X86 V0.5.9](#)
- [Eunhasu X86 V0.6.0](#)

Download Rufus program

- [Download Rufus V3.4](#)

Preparation

1. Prepare a 8GB(or above size) USB disk
2. Write in DD Image mode

Rufus 3.4.1430

Drive Properties

Device: Multiple Partitions (E:) (F:) (G:) [7.9GB]

Boot selection: clonezilla-live-Eunhasu-V0.4.56-0.86_64-2019

Partition scheme: MBR Target system: BIOS or UEFI

Show advanced drive properties

Format Options

Volume label: Eunhasu-V0.4.56-0.86_64-2019_02

File system: FAT32 (Default) Cluster size: 4096 bytes (Default)

Show advanced format options

Status

READY

Using image: clonezilla-live-Eunhasu-V0.4.56-0.86_64-2019_02.iso



Install Eunhasu OS to the SMB-Q370

Connect the USB disk to the USB port of the SMB-Q370

Connect a LCD monitor by a HDMI cable to the SMB-Q370

Connect a USB keyboard to the SMB-Q370 and turn on the PC

Hit a F7 button continuously while booting to go to booting disk selection windows

Select the USB disk and continue booting

Select the first string in Clonezilla windows

Clonezilla live with img Eunhasu-V0.5.5_sMB-Q370_60G_2023-11-29-01-img (VGA 800×600)

Select the installation disk

1. if your disk is M.2(NVME) Disk, select nvme0n1 or nvme0n2
2. if your disk is SATA Disk, select sda or sdb

Select Y or hit Enter if asked whether to continue installations

Once finished installations, reboot the PC

Expand Partition

Login to Eunhasu console

(ID: root / P/W: sotmaudio)

Once Logged in, enter "mc" to continue

Access to /root/install folder

1. if you use M.2(NVME) Disk, run setup_nvme.sh file.
2. if you use SATA Disk, run setup_sata.sh file.

Reboot the SMB-Q370 PC

From:

<https://www.docs.sotm-audio.com/> - **SOtM docs**

Permanent link:

<https://www.docs.sotm-audio.com/doku.php?id=intalling&rev=1753346316>

Last update: **2025/07/24 04:38**

