

# mSD

micro SD

## Windows

1. SD  
 .( 3.0 GB .gz ) [new micro SD card image](#)
2. SD  
 .( 7.9 GB .img )
3. PC [imageUSB](#) ,
4. SMS-200 SD  
 SD PC .

## imageUSB

[imageUSB](#) , USB 가 ,  
 'Refresh Drives' .



USB

USB



'Browse'




'Write'

SD



1. 가 SD SMS-200
2. SMS-200

## SD



The screenshot shows the Windows Disk Management console. At the top, a table lists the system's volumes. Below this, the graphical layout of Disk 0 and Disk 1 is shown. Disk 0 is a 59.98 GB Basic disk with three partitions: a 450 MB Recovery Partition, a 99 MB EFI System Partition, and a 59.45 GB NTFS Primary Partition (C:). Disk 1 is a 7.45 GB Removable disk with four partitions: a 286 MB Primary Partition, a 244 MB Primary Partition, a 6.88 GB Primary Partition, and a 44 MB Unallocated space. A red box highlights the Disk 1 section.

Volume	Layout	Type	File System	Status	Capacity	Free Spa...	% Free
(C:)	Simple	Basic	NTFS	Healthy (B...	59.45 GB	29.60 GB	50 %
(Disk 0 partition 1)	Simple	Basic		Healthy (R...	450 MB	450 MB	100 %
(Disk 0 partition 2)	Simple	Basic		Healthy (E...	99 MB	99 MB	100 %
(Disk 1 partition 1)	Simple	Basic		Healthy (P...	286 MB	286 MB	100 %
(Disk 1 partition 2)	Simple	Basic		Healthy (P...	244 MB	244 MB	100 %
(Disk 1 partition 3)	Simple	Basic		Healthy (P...	6.88 GB	6.88 GB	100 %

Disk	Capacity	Partition 1	Partition 2	Partition 3	Partition 4
Disk 0 Basic 59.98 GB Online	450 MB Healthy (Recovery Partition)	99 MB Healthy (EFI System Partition)	(C:) 59.45 GB NTFS Healthy (Boot, Page File, Crash Dump, Primary Partition)		
Disk 1 Removable 7.45 GB Online	286 MB Healthy (Primary Partition)	244 MB Healthy (Primary Partition)	6.88 GB Healthy (Primary Partition)	44 MB Unallocated	

The screenshot shows the Windows Disk Management utility. At the top, a table lists the system's volumes:

Volume	Layout	Type	File System	Status	Capacity	Free Spa...	% Free
(C:)	Simple	Basic	NTFS	Healthy (B...	59.45 GB	29.60 GB	50 %
(Disk 0 partition 1)	Simple	Basic		Healthy (R...	450 MB	450 MB	100 %
(Disk 0 partition 2)	Simple	Basic		Healthy (E...	99 MB	99 MB	100 %
(Disk 1 partition 1)	Simple	Basic		Healthy (P...	286 MB	286 MB	100 %
(Disk 1 partition 2)	Simple	Basic		Healthy (P...	244 MB	244 MB	100 %
(Disk 1 partition 3)	Simple	Basic		Healthy (P...	6.88 GB	6.88 GB	100 %

Below the table, the detailed view for Disk 1 (Removable, 7.45 GB) is shown. It contains four partitions: a 286 MB Primary Partition (shaded), a 244 MB Primary Partition, a 6.88 GB Primary Partition, and a 44 MB Unallocated space. A context menu is open over the 6.88 GB partition, with the 'Delete Volume...' option highlighted in red. A red text box on the right side of the screenshot reads: 'Click right button of mouse Delete Volume 3 patitions of Disk1(mSD CARD) It will be changed to 1 of unallocated disk'.





## macOS


1. SD ( 3.0 GB .gz ) new micro SD card image
2. dd-utility . <https://www.thefanclub.co.za> github
3. SMS-200 SD PC SD


## Start Restore

dd-utility 'Restore' .img



SD





sMS-200

SD

## dd-utility

- [imageUSB for Windows](#)
- [dd-utility for macOS](#)

## micro SD card

- [Eunhasu V0.4.22](#)
- [Eunhasu V0.5.1](#)
- [Eunhasu V0.5.2](#)
- [Eunhasu V0.5.31](#)
- [Eunhasu V0.5.41](#)
- [Eunhasu V0.5.51](#)

From:

<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:

[https://www.docs.sotm-audio.com/doku.php?id=ko:eunhasu:burn\\_sdcard\\_image&rev=1704257759](https://www.docs.sotm-audio.com/doku.php?id=ko:eunhasu:burn_sdcard_image&rev=1704257759)

Last update: **2024/01/02 23:55**

