

mSD


micro SD

Windows

1. SD
.(3.0 GB .gz) [new micro SD card image](#)
2. SD
.(7.9 GB .img)
3. PC [imageUSB](#) ,
4. SMS-200 SD
SD PC .


imageUSB

[imageUSB](#) , USB 가 ,
'Refresh Drives' .



USB

USB



'Browse'




'Write'

SD



1. 가 SD SMS-200
2. SMS-200

SD



The screenshot shows the Windows Disk Management console. At the top, a table lists the system's volumes. Below this, the details for Disk 0 and Disk 1 are shown. Disk 0 is a basic disk with a total capacity of 59.98 GB. It contains three partitions: a 450 MB Recovery Partition, a 99 MB EFI System Partition, and a 59.45 GB NTFS Primary Partition (C:). Disk 1 is a removable disk with a total capacity of 7.45 GB. It contains three partitions: a 286 MB Primary Partition, a 244 MB Primary Partition, and a 6.88 GB Primary Partition. A 44 MB Unallocated space is also present on Disk 1. A red box highlights the Disk 1 section. A legend at the bottom indicates that black represents Unallocated space and blue represents Primary partitions.

Volume	Layout	Type	File System	Status	Capacity	Free Spa...	% Free
(C:)	Simple	Basic	NTFS	Healthy (B...	59.45 GB	29.60 GB	50 %
(Disk 0 partition 1)	Simple	Basic		Healthy (R...	450 MB	450 MB	100 %
(Disk 0 partition 2)	Simple	Basic		Healthy (E...	99 MB	99 MB	100 %
(Disk 1 partition 1)	Simple	Basic		Healthy (P...	286 MB	286 MB	100 %
(Disk 1 partition 2)	Simple	Basic		Healthy (P...	244 MB	244 MB	100 %
(Disk 1 partition 3)	Simple	Basic		Healthy (P...	6.88 GB	6.88 GB	100 %

Disk	Capacity	Partition 1	Partition 2	Partition 3	Partition 4
Disk 0 Basic 59.98 GB Online	450 MB Healthy (Recovery Partition)	99 MB Healthy (EFI System Partition)	(C:) 59.45 GB NTFS Healthy (Boot, Page File, Crash Dump, Primary Partition)		
Disk 1 Removable 7.45 GB Online	286 MB Healthy (Primary Partition)	244 MB Healthy (Primary Partition)	6.88 GB Healthy (Primary Partition)	44 MB Unallocated	
CD-ROM 0 DVD (D:)	No Media				

■ Unallocated ■ Primary partition







macOS

1. SD (3.0 GB .gz) new micro SD card image
2. dd-utility . <https://www.thefanclub.co.za> github
3. SMS-200 SD PC SD


Start Restore

dd-utility 'Restore' .img



SD





sMS-200

SD

dd-utility

- [imageUSB for Windows](#)
- [dd-utility for macOS](#)

micro SD card

- [Eunhasu V0.4.22](#)
- [Eunhasu V0.5.1](#)
- [Eunhasu V0.5.2](#)
- [Eunhasu V0.5.31](#)
- [Eunhasu V0.5.41](#)
- [Eunhasu V0.5.51](#)
- [Eunhasu V0.5.62](#)
- [Eunhasu V0.5.7](#)
- [Eunhasu V0.5.8](#)
- [Eunhasu V0.5.9](#)
- [Eunhasu V0.6.0](#)

From:

<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:

https://www.docs.sotm-audio.com/doku.php?id=ko:eunhasu:burn_sdcard_image&rev=1753163030

Last update: **2025/07/22 01:43**

